

ASSEMBLING INSTRUCTION**BAR END - BMW**
BMW1000-10 ADAPTER FITTING**WWW.BARRACUDAMOTO.COM****PARTS TO USE :**

1. M6 SCREW
3. INSERT
INSERTO
INSERTO
METALLEINSATZ
INSERT
4. BAR END
ANTIVIBRANTE
ANTIVIBRACION
LENKERGEWICHTE
EMBOUT DE GUIDON
5. SPACER
SPESSORE
ANTIVIBRACION
ABSTANDSHALTER
ESPACEUR

COMPLETE SET